

GENERAL INFORMATION

Standard Convertible / Bimini Top Enclosures

TOOLS REQUIRED

EXTENSION CORD
ELECTRIC DRILL
9/64" DRILL BIT
PHILLIPS HEAD SCREWDRIVER
SCRATCH AWL
PENCIL
SAFETY GOGGLES



WARNING

INDICATES POTENTIAL HAZARD THAT COULD RESULT IN DEATH OR INJURY



CAUTION

INDICATES POTENTIAL HAZARD THAT COULD RESULT IN BOAT DAMAGE



NOTE

Indicates special information to make maintenance easier or instructions clearer

INSTALLATION

STEP 1

Make sure your canopy is centered on the frame for a smooth fit. This is important.

STEP 2

Zipper all curtains to canopy top.

STEP 3

Install snap studs and windshield clips as needed. Pre-drilling may be necessary (especially in fiberglass) to avoid scratching or cracking the gunnel while installing the screw studs.

STEP 4

For best results, center the aft curtain and install the corner snaps first.



WARNING

IF USING ELECTRICAL TOOLS DURING INSTALLATION, DO NOT INSTALL FASTENERS WHILE BOAT IS ON OR NEAR WATER.



NOTE

If your boat is made of fiberglass, extra care should be taken when installing the screw studs into the boat. After the hole is drilled, using a 9/64" drill bit, take a Phillips head screwdriver and lightly chamfer the outer edge of the hole. Failure to chamfer the hole will result in cracking & chipping of the fiberglass finish. If your boat is made of aluminum, chamfering is not necessary unless a chip is exposed. Use care when working with aluminum as chips may be sharp and cause personal injury or damage the cover & boat finish. Use an assistant to help in the installation process.

CARE

For storage, it is recommended that curtains be rolled in lieu of folding. Folding curtains could place creases in the vinyl windows causing premature damage.



WARNING

DO NOT TRAILER BOAT WITH ANY CANOPY TOP UP (IN RADAR ARCH POSITION) OR WITH THE ENCLOSURE ASSEMBLED!